



Technical Bulletin

Subject: **CD Changer, Error Codes**

Group: **91**

Number: **98-07**

Model(s): **All with Panasonic CD Changer 1998 ►**

Date: **June 10, 1998**

Service

The following chart shows the possible error codes for Panasonic CD Changers.

Error Code	Description
CD1ERR1	Compact Disc Dirty or improperly installed
CD1ERR2	Compact Disc has scratches
CD1ERR3	Malfunction in the mechanical system of the CD Changer

Note:

This information is also available in the Owner's Literature for the CD Changer.