


Note:

Do not use a pin or other sharp objects, as these will damage the washer jets.

Windshield washer jet settings

- Mark the top of the area where the spray jets should contact the glass using a water-soluble marker pen.




A

- Adjust the height setting of the washer jet (fan-shaped spray pattern) using a screwdriver.

Note:

The distance is measured from the washer jet.



A

Distance:
a - 400 mm